

Blocked Drains    High Pressure Water Jetting    Colour Camera Surveys    Septic Tank Emptying  
Combination Lorry Jetting    Root Cutting    Drain Repair    Road Gully Emptying

## METHOD STATEMENT (JETTING)

<u>TASK</u>	To high pressure jet clean drains and uplift resulting debris
<u>EQUIPMENT</u>	Jetting unit capable of jetting drain. Manhole lifting equipment. Cones, signs and barriers as appropriate
<u>PROTECTIVE CLOTHING</u>	Hard hat, waterproof overalls, gloves Ear/eye protection, safety boots High visibility jacket
<u>ADDITIONAL EQUIPMENT</u>	Gas detector, first aid, telephone Mega-Rod written Safety Policy in vehicle
<u>METHOD</u>	Ensure area is safe, gas test surface of cover, set up cones, signs or barriers  Position lorry to optimise jetting & suction, taking note of any obstructions or overhead power lines  Open cover using manhole-lifting equipment  Gas test drain if man entry required  Locate jet in channel and begin jetting  Connect suction hose and commence suction when required  On completion, close cover and return area to safe condition